A WARNING

These units should be operated only by authorized adults who have read and understand these operating instructions. Movement and/or operation of these tables by children could result in serious injury! It is dangerous to leave children unattended in the area of folded tables. Do not use tables as room dividers. To avoid table tipping over, push from end of table; DO NOT push from side. If necessary to replace or repair leg assemblies, contact Palmer Hamilton. Do not sit or stand on tabletops.

MOVING THE TABLE



CORRECT WAY To avoid table tipping over, push from the end of the folded table, facing the Center Lock




INCORRECT WAY Pushing from the flat table side may cause tipping.

MAINTENANCE TIPS

- 1. Lubricate up and down latches on a regular basis.
- 2. Check nuts and bolts on a regular basis.
- 3. Lubricate all pivot points as required.
- 4. Use mild soap and water, damp sponge for general cleaning. For tougher stains, visit wilsonart.com.
- 5. DO NOT power wash!

TO OPEN THE TABLE FOR IN-USE POSITION



While placing one hand below caution label, grasp lower edge of table and lift slowly.



Open table until Lock Rod engages in safety position.



STEP 2 To fully open the table, lift table slightly (1-2 inches) and release Lock Rod



STEP 3 Lower the tabletop to open position.


TO CLOSE THE TABLE FOR STORAGE POSITION



Locate the Lock Rod with one hand and place other hand on table edge.



Close-up of Center Lock



STEP 2 Raise Lock Rod toward the tabletop.



STEP 3 Lift the table at the center while pushing down on edge.



Customer Service 800-788-1028

As part of Palmer Hamilton's on-going commitment to quality, product specifications, changes, or modifications may be made without prior notice. Warranty: PALMER HAMILTON warrants that its products shall be free from defects in original material and workmanship for a period of fifteen years from the original shipment date. This warranty shall not apply to normal wear and tear or in the event products are damaged as a result of misuse, abuse, vandalism, neglect, accident, improper application, and modification or repair by persons not authorized by PALMER HAMILTON. The company will, at its discretion, repair or replace any defects. Any repair or replacement must be approved in advance by the factory before any action is taken. There are no implied warranties of fitness or merchantability, and there are no other express warranties beyond the warranties expressed here. 10/2010